

Septic-Clear™ for contractors

Septic-Clear™ protocol for Hydro Jetting and Pressure Bag

Hydro Jetting a septic field: use normal jetting protocols mixing a 2% - 5% solution of Septic-Clear™ into your water source. Septic-Clear™ will instantly break down any scum (FOG) that has migrated into the field. Septic-Clear™ is a biological catalyst with all the seeding needed for a full restoration.

Pressure Bag the inlet to the leach field: after pumping the septic tank insert a pressure bag into the leach field inlet. Using a mixture of 5% Septic-Clear™ with water (55-gallon drum) and a pump, inject directly into Septic Field inlet. Septic-Clear™ is a biological catalyst with all the seeding needed for a full restoration.